

FRUIT VAN 'FRUIT D'

Lot no: 30345	Builder: Swindon	Ordered: 01/1956	FRUIT D
Diagram: 805			Completed: 06/1958
023999	92038	Leamington Spa Station	Stores Van
024240	92027	Wolverhampton Oxley CS	Stores Van

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30563	Builder: Earlestown	Ordered: 01/1959	CCT
Diagram: 816	Design Code: NP501		Completed: 12/1960
024438	94572	Speke Yard, Liverpool	Stores Van
			Grounded body
Lot no: 30562	Builder: Earlestown	Ordered: 01/1959	Completed: 07/1960
Diagram: 816	Design Code: NP501		
024457	94344	Crewe Gresty Road OTPD	Stores Van
			Grounded body
Lot no: 30549	Builder: Earlestown	Ordered: 11/1958	Completed: 03/1960
Diagram: 816	Design Code: NP501		
024458	94127	Crewe Gresty Road S&T Yard	Stores Van

FIRST CLASS RESTAURANT (with Kitchen)

Lot no: 30633	Builder: Ashford/Swindon	Ordered: 10/1959	RFK
Diagram: 17	Design Code: AL101	Seats: 24F	Completed: 01/1962
			Bogies: CW
024460	1780	323	Carlisle Upperby
			Staff Coach
			Originally at Heysham Harbour, later Manchester Ashton Road WRD

TOURIST OPEN SECOND

Lot no: 30086	Builder: Ashford/Eastleigh	Ordered: 04/1953	TSO
Diagram: 93	Design Code: AC204	Seats: 64S	Completed: 01/1955
			Bogies: BR1
024462	3954		Carlisle Upperby
			Staff Coach
			Originally at Heysham Harbour

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30563	Builder: Earlestown	Ordered: 01/1959	CCT
Diagram: 816	Design Code: NP501		Completed: 12/1960
024463	94474	Liverpool Downhill CS	Stores Van

OPEN SECOND

Lot no: 30031	Builder: Derby	Ordered: 03/1951	SO
Diagram: 94	Design Code: AD201	Seats: 48S	Completed: 09/1954
			Bogies: BR1
024464	3732		Wolverton Works
			Stores Coach

FIRST CLASS RESTAURANT (with Kitchen)

Lot no: 30633	Builder: Ashford/Swindon	Ordered: 10/1959	RFK
Diagram: 17	Design Code: AL101	Seats: 24F	Completed: 01/1962
			Bogies: CW
024476	1639	338	Wembley CARMD
			Staff Coach
			Originally at Euston Downside CS

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30563	Builder: Earlestown	Ordered: 01/1959	CCT
Diagram: 816	Design Code: NP501		Completed: 12/1960
024497	94507	RTC-Hartley House, Derby	Stores & Workshop Van
			Originally at RTC-Derby

UNCLASSIFIED RESTAURANT BUFFET (with Kitchen)

Lot no: 30527	Builder: BRCW	Ordered: 08/1958	RUKB
Diagram: 24	Design Code: AJ402	Seats: 23U	Completed: 07/1961
			Bogies: CW
024498	1749		Liverpool Downhill CS
			Staff Coach
024607	1741		Preston North Union Yard
			Staff Coach
			Originally at Aberystwyth
			Originally at Preston Dock Street

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30562	Builder: Earlestown	Ordered: 01/1959	CCT
Diagram: 816	Design Code: NP501		Completed: 07/1960
024608	94395	Preston Dock Street	Stores Van
			Originally at Holyhead
Lot no: 30549	Builder: Earlestown	Ordered: 11/1958	Completed: 03/1960
Diagram: 816	Design Code: NP501		
024609	94149	Nottingham CS	Seat Store
			Originally at Derby Etches Park

Lot no: 30564 Diagram: 816	Builder: Earlestown Design Code: NP501	Ordered: 01/1959	Completed: 03/1961
024610 94605	Nottingham CS	Seat Store	Originally at Derby Etches Park
Lot no: 30549 Diagram: 816	Builder: Earlestown Design Code: NP501	Ordered: 11/1958	Completed: 03/1960
024611 94237	Manchester Longsight T&RSMD	Stores Van	
Lot no: 30614 Diagram: 816	Builder: Earlestown Design Code: NP501	Ordered: 06/1959	Completed: 04/1961
024624 94891	Fazakerley EY	Stores Van	
Lot no: 30562 Diagram: 816	Builder: Earlestown Design Code: NP501	Ordered: 01/1959	Completed: 07/1960
024665 94410	Toton TMD	Stores Van	

BRAKE CORRIDOR SECOND

Lot no: 30032 Diagram: 181	Builder: Wolverton Design Code: AB201	Ordered: 03/1951 Seats: 24S	Completed: 11/1952 Bogies: BR1
024667 975197 34375	Nottingham CS	Stores Van	Originally at Derby Etches Park
Lot no: 30141 Diagram: 181	Builder: GRCW Design Code: AB201	Ordered: 01/1954 Seats: 24S	Completed: 06/1955 Bogies: BR1
024668 975198 34609	Nottingham CS	Stores Van	Originally at Derby Etches Park

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30549 Diagram: 816	Builder: Earlestown Design Code: NP501	Ordered: 11/1958	Completed: 03/1960
024672 94142	Manchester Longsight T&RSMD	Stores Van	

CORRIDOR COMPOSITE

Lot no: 30135 Diagram: 128	Builder: Metro-Cammell Design Code: AA302	Ordered: 01/1954 Seats: 24F,24S	Completed: 07/1955 Bogies: BR1
024687 745187 15571	Wolverhampton Steel Terminal	Equipment Carrier	Bodywork removed & converted to Carflat Originally at Birmingham Lawley Street FLT
Lot no: 30075 Diagram: 126	Builder: Derby Design Code: AA301	Ordered: 01/1953 Seats: 24F,18S	Completed: 07/1954 Bogies: BR1
024689 745010 15355	Derby Litchurch Lane Works	Equipment Carrier	Bodywork removed & converted to Carflat.

CORRIDOR SECOND

Lot no: 30155 Diagram: 147	Builder: Wolverton Design Code: AA202	Ordered: 04/1954 Seats: 64S	Completed: 05/1956 Bogies: BR1
024690 745013 25151	Derby Litchurch Lane Works	Equipment Carrier	Bodywork removed & converted to Carflat.

CORRIDOR COMPOSITE

Lot no: 30005 Diagram: 126	Builder: Metro-Cammell Design Code: AA301	Ordered: 12/1950 Seats: 24F,18S	Completed: 10/1953 Bogies: BR1
024691 745038 15126	Derby Litchurch Lane Works	Equipment Carrier	Bodywork removed & converted to Carflat

CORRIDOR SECOND

Lot no: 30155 Diagram: 147	Builder: Wolverton Design Code: AA202	Ordered: 04/1954 Seats: 64S	Completed: 05/1956 Bogies: BR1
024692 745054 25145	Derby Litchurch Lane Works	Equipment Carrier	Bodywork removed & convetred to Carflat
Lot no: 30044 Diagram: 146	Builder: York Design Code: AA201	Ordered: 04/1951 Seats: 48S	Completed: 11/1952 Bogies: BR1
024693 745068 24565	Derby Litchurch Lane Works	Equipment Carrier	Bodywork removed & converted to Carflat

SECOND [non-gangwayed]

Lot no: 30037 Diagram: 327	Builder: Swindon	Ordered: 03/1951 Seats: 120S	Completed: 02/1955 Bogies: BR2
-------------------------------	------------------	---------------------------------	-----------------------------------

024694	745608	46051	Derby Litchurch Lane Works	Equipment Carrier	Bodywork removed & converted to Carflat
---------------	--------	-------	----------------------------	-------------------	---

FISH VAN

Lot no: 30125	Builder: Earlestown	Ordered: 08/1953	Completed: 02/1955
Diagram: 800	Design Code: NR502		

024709	975892	87122	Wembley Heavy Repair Depot	Seat Store
024710	975893	87146	Wembley Heavy Repair Depot	Seat Store
024711	975891	87227	Wembley Heavy Repair Depot	Seat Store

GENERAL UTILITY VAN

Lot no: 30616	Builder: Pressed Steel	Ordered: 07/1959	Completed: 06/1960
Diagram: 811	Design Code: NI501		Bogies: BR2

024719	93923	86923	Chester Wagon Repair Depot	Stores Van
---------------	-------	-------	----------------------------	------------

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30562	Builder: Earlestown	Ordered: 01/1959	Completed: 07/1960
Diagram: 816	Design Code: NP501		

024720	94442		Chester Depot	Stores Van
---------------	-------	--	---------------	------------

Lot no: 30614	Builder: Earlestown	Ordered: 06/1959	Completed: 04/1961
Diagram: 816	Design Code: NP501		

024721	94705		Chester Depot	Stores Van
---------------	-------	--	---------------	------------

PASSENGER BRAKE, GANGWAYED

Lot no: 30140	Builder: BRCW	Ordered: 01/1954	Completed: 01/1956
Diagram: 711	Design Code: NA501		Bogies: BR1

024743	80788		Chester Brook Sidings	S&T Stores Van
---------------	-------	--	-----------------------	----------------

GENERAL UTILITY VAN

Lot no: 30417	Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811	Design Code: NI501		Bogies: BR2

024753	93203	86203	Crewe Gresty Lane OTPD	Stores Van	Originally at Chester WRD
---------------	-------	-------	------------------------	------------	---------------------------

SECOND [non-gangwayed]

Lot no: 30037	Builder: Swindon	Ordered: 03/1951	Completed: 02/1955
Diagram: 327		Seats: 120S	Bogies: BR2

024783	745628	46052	Camden CS	Equipment Carrier	Bodywork removed & converted to Carflat
---------------	--------	-------	-----------	-------------------	---

TOURIST OPEN SECOND

Lot no: 30043	Builder: Doncaster	Ordered: 04/1951	Completed: 12/1953
Diagram: 93	Design Code: AC204	Seats: 64S	Bogies: BR1

024784	3744		Toton Training School	Classroom Coach
---------------	------	--	-----------------------	-----------------

GENERAL UTILITY VAN

Lot no: 30417	Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811	Design Code: NI501		Bogies: BR2

024787	93219	86219	Nottingham Eastcroft OTPD	Stores Van	Grounded body
---------------	-------	-------	---------------------------	------------	---------------

PASSENGER BRAKE, GANGWAYED

Lot no: 30140	Builder: BRCW	Ordered: 01/1954	Completed: 01/1956
Diagram: 711	Design Code: NA501		Bogies: BR1

024820	80752		Blackpool CARMD	Stores Van
---------------	-------	--	-----------------	------------

GENERAL UTILITY VAN

Lot no: 30402	Builder: York/Glasgow	Ordered: 07/1956	Completed: 07/1960
Diagram: 811	Design Code: NI501		Bogies: BR2

024821	93594	86594	Blackpool CARMD	Stores Van
---------------	-------	-------	-----------------	------------

BRAKE CORRIDOR SECOND

Lot no: 30233	Builder: GRCW	Ordered: 04/1955	Completed: 06/1957
Diagram: 181	Design Code: AB201	Seats: 24S	Bogies: BR1

024822	975956	35061	RTC-Hartley House, Derby	Laboratory Coach	Originally at RTC-Derby
---------------	--------	-------	--------------------------	------------------	-------------------------

Fish

GUV

CCT

BG

GUV

S

TSO

GUV

BG

GUV

BSK

GENERAL UTILITY VAN

Lot no: 30417	Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811	Design Code: NI501		Bogies: BR2

024823 93483 86483 Wolverhampton Oxley CS Seat Store Grounded body

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30651	Builder: Earlestown	Ordered: 10/1959	Completed: 04/1961
Diagram: 816	Design Code: NP501		

024824 94919 Chester Wagon Repair Depot Stores Van

Lot no: 30562	Builder: Earlestown	Ordered: 01/1959	Completed: 07/1960
Diagram: 816	Design Code: NP501		

024825 94335 Chester Wagon Repair Depot Stores Van

PASSENGER BRAKE, GANGWAYED

Lot no: 30400	Builder: Pressed Steel	Ordered: 05/1956	Completed: 01/1958
Diagram: 711	Design Code: NA501		Bogies: BR1

024872 84358 81358 RTC-Derby Stores Van

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30614	Builder: Earlestown	Ordered: 06/1959	Completed: 04/1961
Diagram: 816	Design Code: NP501		

024877 94698 Liverpool Wavertree Yard Carriage Cleaning Store

GENERAL UTILITY VAN

Lot no: 30417	Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811	Design Code: NI501		Bogies: BR2

024889 93392 86392 Derby Etches Park Seat Store

Lot no: 30616	Builder: Pressed Steel	Ordered: 07/1959	Completed: 06/1960
Diagram: 811	Design Code: NI501		Bogies: BR2

024890 93913 86913 Derby Etches Park Chemical Store

OPEN BRAKE SECOND

Lot no: 30757	Builder: Derby	Ordered: 04/1965	Completed: 08/1966
Diagram: 185	Design Code: AE203	Seats: 31S	Bogies: B4

024909 9106 9406 Preston Station Staff /Storage Coach

PASSENGER BRAKE, GANGWAYED

Lot no: 30228	Builder: Metro-Cammell	Ordered: 04/1955	Completed: 05/1958
Diagram: 711	Design Code: NA501		Bogies: BR1

024914 84114 81114 Derby Etches Park Stores Van

GENERAL UTILITY VAN

Lot no: 30417	Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811	Design Code: NI501		Bogies: BR2

024918 93402 86402 Willesden Brent Sidings Stores Van

Lot no: 30565	Builder: Pressed Steel	Ordered: 01/1959	Completed: 10/1959
Diagram: 811	Design Code: NI501		Bogies: BR2

024919 93697 86697 Wembley Yard Stores Van

024921 93822 86822 Manchester Longsight T&RSMD Stores Van

PASSENGER BRAKE, GANGWAYED

Lot no: 30400	Builder: Pressed Steel	Ordered: 05/1956	Completed: 01/1958
Diagram: 711	Design Code: NA501		Bogies: BR1

024926 84390 81390 Carlisle Upperby Stores Van

024927 84332 81332 Camden CS Stores Van Originally at Euston Downside CS

TRAILER SECOND with Lavatory

Lot no: 30493	Builder: Derby	Ordered: 11/1957	Completed: 11/1958
Diagram: 545	Design Code: DT206	Seats: 68S	

024949 59389 Tyseley DMUD Stores Coach

Grounded body

GENERAL UTILITY VAN

GUV

BRAKE CORRIDOR SECOND

Lot no: 30229	Builder: Metro-Cammell	Ordered: 04/1955	Completed: 04/1957
Diagram: 182	Design Code: AB202	Seats: 32S	Bogies: BR1
025030	889302 99204 34995	Stafford S&T Siding	Stores Van
			Former Bullion Van

BSK

FISH VAN

Lot no: 30125	Builder: Earlestown	Ordered: 08/1953	Completed: 02/1955
Diagram: 800	Design Code: NR502		
041312	87249	Ferne Park CS	Stores Van
			Became DB975961
Lot no: 30442	Builder: Faverdale	Ordered: 11/1956	Completed: 10/1961
Diagram: 801	Design Code: NR502		
041313	975351 87980	Lowestoft	Stores Van
Lot no: 30384	Builder: Faverdale	Ordered: 04/1956	Completed: 01/1961
Diagram: 801	Design Code: NR502		
041314	975352 87902	Norwich Thorpe Yard	Stores Van
Lot no: 30344	Builder: Faverdale	Ordered: 01/1956	Completed: 01/1961
Diagram: 801	Design Code: NR502		
041315	975353 87558	Norwich Thorpe Yard	Stores Van
041316	975354 87506	Norwich Thorpe Yard	Stores Van
041317	975355 87616	Norwich Crown Point T&RSMD	Chemical Store
041318	975356 87656	Norwich Thorpe Yard	Originally at Norwich Thorpe Yard
041319	975357 87525	Thetford	Stores Van
Lot no: 30384	Builder: Faverdale	Ordered: 04/1956	Completed: 01/1961
Diagram: 801	Design Code: NR502		
041320	975358 87730	Norwich Thorpe Yard	Stores Van
Lot no: 30344	Builder: Faverdale	Ordered: 01/1956	Completed: 01/1961
Diagram: 801	Design Code: NR502		
041321	975359 87602	Norwich Thorpe Yard	Refuse Disposal Van
Lot no: 30442	Builder: Faverdale	Ordered: 11/1956	Completed: 10/1961
Diagram: 801	Design Code: NR502		
041322	975360 88053	Norwich Thorpe Yard	Stores Van

CK

CORRIDOR COMPOSITE

Lot no: 30005	Builder: Metro-Cammell	Ordered: 12/1950	Completed: 10/1953
Diagram: 126	Design Code: AA301	Seats: 24F,18S	Bogies: BR1
041327	975092 15147	Tyneside Central Freight Depot	Cartic Ramp
			Bodywork removed

OPEN BRAKE SECOND

BSO

Lot no: 30170	Builder: Doncaster	Ordered: 05/1954	Completed: 03/1956
Diagram: 183	Design Code: AE201	Seats: 39S	Bogies: BR1
041332	975269 9269	Hitchin	S&T Office Coach
Lot no: 30125	Builder: Earlestown	Ordered: 08/1953	Completed: 02/1955
Diagram: 800	Design Code: NR502		
041420	87318	Norwich Thorpe Yard	Paper Stores Van
Lot no: 30344	Builder: Faverdale	Ordered: 01/1956	Completed: 01/1961
Diagram: 801	Design Code: NR502		
041474	975418 87614	Workshop Up Yard	C&W Stores Van
			Previously at Workshop MGR Wagon Depot Originally at Workshop Station Yard Grounded body
Lot no: 30384	Builder: Faverdale	Ordered: 04/1956	Completed: 01/1961
Diagram: 801	Design Code: NR502		
041475	87706	Shirebrook TMD	Tool Van
041500	87727	Doncaster Works	Stores Van
Lot no: 30125	Builder: Earlestown	Ordered: 08/1953	Completed: 02/1955
Diagram: 800	Design Code: NR502		
041504	87358	York Clifton CS	Stores Van

Fish

BRAKE CORRIDOR COMPOSITE

BCK

Lot no: 30185 Diagram: 171	Builder: Metro-Cammell Design Code: AB301	Ordered: 07/1954 Seats: 12F,18S	Completed: 05/1956 Bogies: BR1
041526	21095	Heaton CS	Staff Coach
HORSE BOX			HB
Lot no: 30146 Diagram: 751	Builder: Earlestown	Ordered: 03/1954	Completed: 10/1958
041554	321100 96327	Doncaster Works	Boiler Van
PASSENGER BRAKE, GANGWAYED			BG
Lot no: 30162 Diagram: 711	Builder: Pressed Steel Design Code: NA501	Ordered: 04/1954	Completed: 09/1957 Bogies: BR1
041570	80963	Doncaster Works	Stores Van
COVERED CARRIAGE TRUCK (four-wheeled)			CCT
Lot no: 30563 Diagram: 816	Builder: Earlestown Design Code: NP501	Ordered: 01/1959	Completed: 12/1960
041580	94550	Scarborough	Stores Van
PASSENGER BRAKE, GANGWAYED			BG
Lot no: 30173 Diagram: 711	Builder: York Design Code: NA501	Ordered: 05/1954	Completed: 07/1956 Bogies: BR1
041597	80990	Shirebrook TMD	Stores Van
BRAKE CORRIDOR COMPOSITE			Originally at Lincoln depot
Lot no: 30425 Diagram: 171	Builder: Metro-Cammell Design Code: AB301	Ordered: 10/1956 Seats: 12F,18S	BCK
041605	21219	Hornsey Up CS	Staff Coach
TOURIST OPEN SECOND			Originally at Ferme Park CS
Lot no: 30375 Diagram: 93	Builder: York Design Code: AC204	Ordered: 06/1957 Seats: 64S	TSO
041606	4688	Hornsey Up CS	Staff Coach
PASSENGER BRAKE, GANGWAYED			BG
Lot no: 30039 Diagram: 711	Builder: Derby Design Code: NA501	Ordered: 03/1951	Completed: 10/1954 Bogies: BR1
041612	80557	Doncaster Works	Stores Van
Lot no: 30400 Diagram: 711	Builder: Pressed Steel Design Code: NA501	Ordered: 05/1956	Completed: 01/1958 Bogies: BR1
041613	81446	York Clifton CS	Stores Van
Lot no: 30046 Diagram: 711	Builder: York Design Code: NA501	Ordered: 04/1951	Originally at Healey Mills Yard
041623	80641	York Works	Stores Van
Lot no: 30040 Diagram: 711	Builder: Wolverton Design Code: NA501	Ordered: 03/1951	Completed: 09/1954 Bogies: BR1
041624	80568	York Works	Stores Van
Lot no: 30140 Diagram: 711	Builder: BRCW Design Code: NA501	Ordered: 01/1954	Completed: 01/1955 Bogies: BR1
041625	80770	York Works	Stores Van
COVERED CARRIAGE TRUCK (four-wheeled)			CCT
Lot no: 30563 Diagram: 816	Builder: Earlestown Design Code: NP501	Ordered: 01/1959	Completed: 12/1960
041626	977002 94493	Crofton EY	Stores Van
Lot no: 30614 Diagram: 816	Builder: Earlestown Design Code: NP501	Ordered: 06/1959	Grounded body
041627	977003 94711	Crofton EY	Stores Van
Lot no: 30549 Diagram: 816	Builder: Earlestown Design Code: NP501	Ordered: 11/1958	Completed: 04/1961
041628	977004 94114	Dinsdale EY	Stores Van
			Grounded body

Lot no: 30614 Diagram: 816		Builder: Earlestown Design Code: NP501	Ordered: 06/1959	Completed: 04/1961
041629	977005 94775	Dinsdale EY	Stores Van	Grounded body
PASSENGER BRAKE, GANGWAYED				BG
Lot no: 30144 Diagram: 711		Builder: Cravens Design Code: NA501	Ordered: 01/1954	Completed: 12/1955 Bogies: BR1
041636	80846	York Works	Stores Van	
Lot no: 30228 Diagram: 711		Builder: Metro-Cammell Design Code: NA501	Ordered: 04/1955	Completed: 05/1958 Bogies: BR1
041637	81058	York Works	Stores Van	
COVERED CARRIAGE TRUCK (four-wheeled)				CCT
Lot no: 30563 Diagram: 816		Builder: Earlestown Design Code: NP501	Ordered: 01/1959	Completed: 12/1960
041638	94522	Wakefield Kirkgate S&T Depot	Stores Van	
041639	94496	Wakefield Kirkgate S&T Depot	Stores Van	
Lot no: 30564 Diagram: 816		Builder: Earlestown Design Code: NP501	Ordered: 01/1959	Completed: 03/1961
041640	94630	Wakefield Kirkgate S&T Depot	Stores Van	
Lot no: 30563 Diagram: 816		Builder: Earlestown Design Code: NP501	Ordered: 01/1959	Completed: 12/1960
041641	94589	Wakefield Kirkgate S&T Depot	Stores Van	
TOURIST OPEN SECOND				TSO
Lot no: 30243 Diagram: 93		Builder: York Design Code: AC204	Ordered: 05/1955 Seats: 64S	Completed: 01/1957 Bogies: BR1
041642	4576	Shildon Works	Staff Coach	
041643	4490	Shildon Works	Staff Coach	
COVERED CARRIAGE TRUCK (four-wheeled)				CCT
Lot no: 30562 Diagram: 816		Builder: Earlestown Design Code: NP501	Ordered: 01/1959	Completed: 07/1960
041644	94388	March TMD	Stores Van	
PASSENGER BRAKE, GANGWAYED				BG
Lot no: 30039 Diagram: 711		Builder: Derby Design Code: NA501	Ordered: 03/1951	Completed: 10/1954 Bogies: BR1
041665	80558	Shildon Works	Stores Van	
TOURIST OPEN SECOND				TSO
Lot no: 30525 Diagram: 89		Builder: Wolverton Design Code: AC201	Ordered: 08/1958 Seats: 64S	Completed: 04/1960 Bogies: BR1
041666	4865	Shildon Works	Staff Coach	
COVERED CARRIAGE TRUCK (four-wheeled)				CCT
Lot no: 30562 Diagram: 816		Builder: Earlestown Design Code: NP501	Ordered: 01/1959	Completed: 07/1960
041667	94305	Dinsdale EY	Stores Van	Grounded body
TOURIST OPEN SECOND				TSO
Lot no: 30207 Diagram: 93		Builder: BRCW Design Code: AC204	Ordered: 01/1955 Seats: 64S	Completed: 10/1956 Bogies: BR1
041674	4296	Stratford TMD	Staff Coach	Originally at Temple Mills Yard
Lot no: 30219 Diagram: 93		Builder: Ashford/Swindon Design Code: AC204	Ordered: 03/1955 Seats: 64S	Completed: 09/1957 Bogies: BR1
041675	4408	Stratford TMD	Staff Coach	Originally at Temple Mills Yard
COVERED CARRIAGE TRUCK (four-wheeled)				CCT
Lot no: 30614 Diagram: 816		Builder: Earlestown Design Code: NP501	Ordered: 06/1959	Completed: 04/1961
041676	94887	Harwich Parkeston Quay Yard	Stores Van	Grounded body

Lot no: 30549	Builder: Earlestown	Ordered: 11/1958	Completed: 03/1960
Diagram: 816	Design Code: NP501		

041869	94286	March Station Yard	Stores Van
Lot no: 30614	Builder: Earlestown	Ordered: 06/1959	Completed: 04/1961
Diagram: 816	Design Code: NP501		

041870	94709	March Station Yard	Stores Van
Lot no: 30564	Builder: Earlestown	Ordered: 01/1959	Completed: 03/1961
Diagram: 816	Design Code: NP501		

041871	94657	Cambridge EY	Stores Van
Lot no: 30614	Builder: Earlestown	Ordered: 06/1959	Completed: 04/1961
Diagram: 816	Design Code: NP501		

041872	94825	Cambridge EY	Stores Van
---------------	-------	--------------	------------

PASSENGER BRAKE, GANGWAYED			BG
Lot no: 30716	Builder: GRCW	Ordered: 07/1961	Completed: 12/1962
Diagram: 711	Design Code: NA501		Bogies: BR1

041898	84608	81608	York Warehouse Yard	Stores Van
Lot no: 30046	Builder: York		Ordered: 04/1951	Completed: 09/1954
Diagram: 711	Design Code: NA501			Bogies: BR1

041899	80610	York Warehouse Yard	Stores Van
Lot no: 30323	Builder: Pressed Steel	Ordered: 11/1955	Completed: 10/1957
Diagram: 711	Design Code: NA501		Bogies: BR1

041904	84271	81271	York Warehouse Yard	Stores Van
Lot no: 30136	Builder: Metro-Cammell		Ordered: 01/1954	Completed: 10/1955
Diagram: 711	Design Code: NA501			Bogies: BR1

041905	80721	York Warehouse Yard	Stores Van
---------------	-------	---------------------	------------

FISH VAN			Fish
Lot no: 30384	Builder: Faverdale	Ordered: 04/1956	Completed: 01/1961
Diagram: 801	Design Code: NR502		

041911	975419	87885	Tinsley TMD	Stores Van	Originally at Darnall WRD
---------------	--------	-------	-------------	------------	---------------------------

COVERED CARRIAGE TRUCK (four-wheeled)			CCT
Lot no: 30651	Builder: Earlestown	Ordered: 10/1959	Completed: 04/1961
Diagram: 816	Design Code: NP501		

041912	977104	94911	Sheffield Brightside FT	Stores Van	Originally at Darnall WRD
Lot no: 30614	Builder: Earlestown		Ordered: 06/1959	Completed: 04/1961	
Diagram: 816	Design Code: NP501				

041913	977105	94763	Sheffield Brightside FT	Stores Van	Originally at Darnall WRD
---------------	--------	-------	-------------------------	------------	---------------------------

GENERAL UTILITY VAN			GUV
Lot no: 30417	Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811	Design Code: NI501		Bogies: BR2

041946	93288	86288	Ilford EMUD	Stores Van
041947	93425	86425	Ilford EMUD	Stores Van

PASSENGER BRAKE, GANGWAYED			BG
Lot no: 30224	Builder: Cravens	Ordered: 03/1955	Completed: 06/1956
Diagram: 711	Design Code: NA501		Bogies: BR1

041954	84027	81027	Ipswich WRD	Stores Van
Lot no: 30228	Builder: Metro-Cammell		Ordered: 04/1955	Completed: 05/1958
Diagram: 711	Design Code: NA501			Bogies: BR1

041955	84085	81085	Ipswich WRD	Stores Van	Grounded body
---------------	-------	-------	-------------	------------	---------------

FISH VAN			Fish
Lot no: 30125	Builder: Earlestown	Ordered: 08/1953	Completed: 02/1955
Diagram: 800	Design Code: NR502		

041969	975961	041312	87249	Ferne Park CS	Stores Van
Lot no: 30384	Builder: Faverdale			Ordered: 04/1956	Completed: 01/1961
Diagram: 801	Design Code: NR502				

041970 977064 87894			Ferne Park CS	Stores Van	
PASSENGER BRAKE, GANGWAYED					BG
Lot no: 30136		Builder: Metro-Cammell		Ordered: 01/1954	Completed: 10/1955
Diagram: 711		Design Code: NA501			Bogies: BR1
041973 80681			Hull Paragon	S&T Stores Van	
Lot no: 30323		Builder: Pressed Steel		Ordered: 11/1955	Completed: 10/1957
Diagram: 711		Design Code: NA501			Bogies: BR1
041974 84297 81297			Hull Paragon	S&T Stores Van	Replacement for original 041974
Lot no: 30484		Builder: Pressed Steel		Ordered: 05/1957	Completed: 03/1958
Diagram: 711		Design Code: NA501			Bogies: BR1
041974 84507 81507			York Up Yard	S&T Stores Van	Original 041974
FISH VAN					Fish
Lot no: 30442		Builder: Faverdale		Ordered: 11/1956	Completed: 10/1961
Diagram: 801		Design Code: NR502			
041981 87973			Leyton EY	Stores Van	Grounded body
Lot no: 30384		Builder: Faverdale		Ordered: 04/1956	Completed: 01/1961
Diagram: 801		Design Code: NR502			
041989 975423 87910			Toton Training School	Stores Van	Grounded body Originally at Shirebrook depot
COVERED CARRIAGE TRUCK (four-wheeled)					CCT
Lot no: 30651		Builder: Earlestown		Ordered: 10/1959	Completed: 04/1961
Diagram: 816		Design Code: NP501			
042000 94899			Cambridge T&RSMD	Stores Van	Grounded body
GENERAL UTILITY VAN					GUV
Lot no: 30565		Builder: Pressed Steel		Ordered: 01/1959	Completed: 10/1959
Diagram: 811		Design Code: NI501			Bogies: BR2
042015 93702 86702			Doncaster Works	Stores Van	
BRAKE CORRIDOR SECOND					BSK
Lot no: 30386		Builder: Charles Roberts		Ordered: 05/1956	Completed: 06/1958
Diagram: 181		Design Code: AB201		Seats: 24S	Bogies: BR1
042124 35119			Leeds Neville Hill T&RSMD	Staff Coach	
Lot no: 30095		Builder: Wolverton		Ordered: 04/1953	Completed: 04/1955
Diagram: 181		Design Code: AB201		Seats: 24S	Bogies: BR1
042125 34532			Leeds Neville Hill T&RSMD	Staff Coach	
GENERAL UTILITY VAN					GUV
Lot no: 30565		Builder: Pressed Steel		Ordered: 01/1959	Completed: 10/1959
Diagram: 811		Design Code: NI501			Bogies: BR2
042126 93828 86828			Tinsley TMD	Stores Van	
PASSENGER BRAKE, GANGWAYED					BG
Lot no: 30228		Builder: Metro-Cammell		Ordered: 04/1955	Completed: 05/1958
Diagram: 711		Design Code: NA501			Bogies: BR1
042132 84125 81125			Heaton CS	Stores Van	
042133 84168 81168			Heaton CS	Stores Van	
Lot no: 30234		Builder: Cravens		Ordered: 05/1955	Completed: 03/1957
Diagram: 711		Design Code: NA501			Bogies: BR1
042134 84199 81199			Heaton CS	Stores Van	
GENERAL UTILITY VAN					GUV
Lot no: 30417		Builder: Pressed Steel		Ordered: 03/1958	Completed: 01/1959
Diagram: 811		Design Code: NI501			Bogies: BR2
042135 93213 86213			Heaton CS	Stores Van	
PASSENGER BRAKE, GANGWAYED					BG
Lot no: 30173		Builder: York		Ordered: 05/1954	Completed: 07/1956
Diagram: 711		Design Code: NA501			Bogies: BR1

042147	84003	81003	Cambridge T&RSMD	Stores Van	
Lot no: 30046		Builder: York		Ordered: 04/1951	Completed: 09/1954
Diagram: 711		Design Code: NA501			Bogies: BR1
042148	80638		Ilford EMUD	Stores Van	
GENERAL UTILITY VAN					
Lot no: 30616		Builder: Pressed Steel		Ordered: 07/1959	Completed: 06/1960
Diagram: 811		Design Code: NI501			Bogies: BR2
042154	93975	86975	Ipswich Upper Yard	Stores Van	
PASSENGER BRAKE, GANGWAYED					
Lot no: 30009		Builder: Derby		Ordered: 12/1950	Completed: 04/1953
Diagram: 711		Design Code: NA501			Bogies: BR1
042179	80526		Norwich Crown Point T&RSMD	Stores Van	Grounded body
GENERAL UTILITY VAN					
Lot no: 30565		Builder: Pressed Steel		Ordered: 01/1959	Completed: 10/1959
Diagram: 811		Design Code: NI501			Bogies: BR2
042188	93831	86831	York WRD	Office & Stores Van	
BRAKE SECOND [non-gangwayed]					
Lot no: 30087		Builder: York		Ordered: 04/1953	Completed: 08/1955
Diagram: 371				Seats: 72S	Bogies: BR2
042190	321088	43344	53155	Knottingley TMD	BTU Tool Van
FISH VAN					
Lot no: 30442		Builder: Faverdale		Ordered: 11/1956	Completed: 10/1961
Diagram: 801		Design Code: NR502			
042206	975329	88038	Frodingham TMD	Tool Van	
GENERAL UTILITY VAN					
Lot no: 30616		Builder: Pressed Steel		Ordered: 07/1959	Completed: 06/1960
Diagram: 811		Design Code: NI501			Bogies: BR2
042210	93858	86858	East Ham EMUD	Stores Van	
DRIVING TRAILER COMPOSITE with lavatory					
Lot no: 30468		Builder: Metro-Cammell		Ordered: 05/1957	Completed: 01/1959
Diagram: 630		Design Code: DS302		Seats: 12F, 53S	
042222	54342	56342	Leeds Neville Hill T&RSMD	Service Unit	
BRAKE CORRIDOR COMPOSITE					
Lot no: 30006		Builder: Metro-Cammell		Ordered: 12/1950	Completed: 11/1954
Diagram: 171		Design Code: AB301		Seats: 12F, 18S	Bogies: BR1
042224	975123	21011	Frodingham TMD	Office / Training Coach	
PASSENGER BRAKE, GANGWAYED					
Lot no: 30140		Builder: BRCW		Ordered: 01/1954	Completed: 01/1956
Diagram: 711		Design Code: NA501			Bogies: BR1
042234	80730		Ilford EMUD	Stores Van	
Lot no: 30484		Builder: Pressed Steel		Ordered: 05/1957	Completed: 03/1958
Diagram: 711		Design Code: NA501			Bogies: BR1
042244	92172	81562	Norwich Crown Point	Stores Van	
OPEN BRAKE SECOND					
Lot no: 30170		Builder: Doncaster		Ordered: 05/1954	Completed: 03/1956
Diagram: 183		Design Code: AE201		Seats: 39S	Bogies: BR1
042467	9233		Heaton CS	Staff Coach	NE Region number series
Lot no: 30244		Builder: Doncaster		Ordered: 05/1955	Completed: 08/1956
Diagram: 183		Design Code: AE201		Seats: 39S	Bogies: BR1
042468	9291		Thornaby TMD	Staff Coach	NE Region number series
SECOND [non-gangwayed]					
S					

Page13

Lot no: 30037		Builder: Swindon		Ordered: 03/1951		Completed: 02/1955	
Diagram: 327				Seats: 120S		Bogies: BR2	
060772	46061	Dagenham Dock Down Yard		Cartic Ramp	Bodywork removed Originally at Dover Town Yard		
060773	46041	Parkeston Quay Yard		Cartic Ramp	Bodywork removed		
FISH VAN				Fish			
Lot no: 30125		Builder: Earlestown		Ordered: 08/1953		Completed: 02/1955	
Diagram: 800		Design Code: NR502					
060782	87343	Radyr Yard		Bridge Department Stores Van			
FRUIT VAN 'FRUIT D'				FRUIT D			
Lot no: 30383		Builder: Swindon		Ordered: 04/1956		Completed: 03/1959	
Diagram: 805							
060900	975175	92087	Newbury	Stores Van			
060947	975166	92096	Oxford Station	Parcels Storage Van			
TOURIST OPEN SECOND				TSO			
Lot no: 30011		Builder: York		Ordered: 12/1950		Completed: 05/1951	
Diagram: 92		Design Code: AC203		Seats: 64S		Bogies: BR1	
060969	975201	3701	Cardiff Canton T&RSMD	Staff Coach			
FRUIT VAN 'FRUIT D'				FRUIT D			
Lot no: 30345		Builder: Swindon		Ordered: 01/1956		Completed: 06/1958	
Diagram: 805							
060971	975342	92056	Gloucester New Yard	TOPS Sationery Stores			
PASSENGER BRAKE, GANGWAYED				BG			
Lot no: 30228		Builder: Metro-Cammell		Ordered: 04/1955		Completed: 05/1958	
Diagram: 711		Design Code: NA501				Bogies: BR1	
061003	81163	Cardiff Canton T&RSMD		First Aid Training Coach			
COVERED CARRIAGE TRUCK (four-wheeled)				CCT			
Lot no: 30614		Builder: Earlestown		Ordered: 06/1959		Completed: 04/1961	
Diagram: 816		Design Code: NP501					
061022	94710	Gloucester Old Yard		CCE Stores Van			
CORRIDOR SECOND				SK			
Lot no: 30720		Builder: Derby		Ordered: 08/1961		Completed: 06/1963	
Diagram: 147		Design Code: AA202		Seats: 64S		Bogies: CW	
061025	26109	Sudbrook		First Aid Training Coach			
PASSENGER BRAKE, GANGWAYED				BG			
Lot no: 30323		Builder: Pressed Steel		Ordered: 11/1955		Completed: 10/1957	
Diagram: 711		Design Code: NA501				Bogies: BR1	
061026	81307	Danygraig Wagon Repair Depot		Stores Van			
COVERED CARRIAGE TRUCK (four-wheeled)				CCT			
Lot no: 30562		Builder: Earlestown		Ordered: 01/1959		Completed: 07/1960	
Diagram: 816		Design Code: NP501					
061027	94433	Bristol Marsh Junction OTPD		Workshop Van			
Lot no: 30614		Builder: Earlestown		Ordered: 06/1959		Completed: 04/1961	
Diagram: 816		Design Code: NP501					
061034	94798	Bristol Marsh Junction OTPD		Workshop Van			
Lot no: 30563		Builder: Earlestown		Ordered: 01/1959		Completed: 12/1960	
Diagram: 816		Design Code: NP501					
061035	94510	Bristol Marsh Junction OTPD		Stores Van			
061036	94555	Bristol Marsh Junction OTPD		Stores Van			
FRUIT VAN 'FRUIT D'				FRUIT D			
Lot no: 30383		Builder: Swindon		Ordered: 04/1956		Completed: 03/1959	
Diagram: 805							
061043	975337	92072	Cardiff Cathays	Donor vehicle	Used for Broad Gauge Carriage		

061044	975339	92103	Cardiff Cathays	Donor Vehicle	Replica Used for Broad Gauge Carriage Replica
---------------	--------	-------	-----------------	---------------	---

PASSENGER BRAKE, GANGWAYED

Lot no: 30144	Builder: Cravens	Ordered: 01/1954	Completed: 12/1955
Diagram: 711	Design Code: NA501		Bogies: BR1

061058	977221	80854	Margam WRD	Wagon Hood Recovery Van
---------------	--------	-------	------------	-------------------------

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30549	Builder: Earlestown	Ordered: 11/1958	Completed: 03/1960
Diagram: 816	Design Code: NP501		

061060	94139		Old Oak Common T&RSMD	Salt store	Originally at Reading T&RSMD
061061	94135		Oxford Station	Stores Van	

Lot no: 30562	Builder: Earlestown	Ordered: 01/1959	Completed: 07/1960
Diagram: 816	Design Code: NP501		

061062	94374	Plymouth Laira T&RSMD	Stores Van	Originally at Taunton Station
Lot no: 30563	Builder: Earlestown	Ordered: 01/1959	Completed: 12/1960	

061063	94557	St.Blazey	Stores Van	Originally at Taunton Station
Lot no: 30614		Builder: Earlestown	Ordered: 06/1959	Completed: 04/1961
Diagram: 816		Design Code: NP501		

061064	94852		Plymouth Laira T&RSMD	Stores Van	Originally at Taunton Station
061065	977204	94732	St. Blazey	Wagon Parts Store	

SECOND [non-gangwayed]

Lot no: 30037	Builder: Swindon	Ordered: 03/1951	Completed: 02/1955
Diagram: 327		Seats: 120S	Bogies: BR2

061066	745645	46062	Tavistock Junction Yard	Equipment Carrier	Bodywork removed & converted to Carflat. Originally at Laira T&RSMD
---------------	--------	-------	-------------------------	-------------------	---

PASSENGER BRAKE, GANGWAYED

Lot no: 30046	Builder: York	Ordered: 04/1951	Completed: 09/1954
Diagram: 711	Design Code: NA501		Bogies: BR1

061076	80622		Cardiff Cathays	Stores Van
---------------	-------	--	-----------------	------------

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30549	Builder: Earlestown	Ordered: 11/1958	Completed: 03/1960
Diagram: 816	Design Code: NP501		

061077	977355	94257	St.Blazey	Wagon Parts Store
---------------	--------	-------	-----------	-------------------

GENERAL UTILITY VAN

Lot no: 30417	Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811	Design Code: NI501		Bogies: BR2

061086	93427	86427	Cardiff Cathays	Stores Van
061087	93250	86250	Radyr Yard	Stores Van

Lot no: 30565	Builder: Pressed Steel	Ordered: 01/1959	Completed: 10/1959
Diagram: 811	Design Code: NI501		Bogies: BR2

061088	93661	86661	Radyr Yard	Stores Van
061089	93676	86676	Radyr Yard	Stores Van

Lot no: 30402	Builder: York/Glasgow	Ordered: 07/1956	Completed: 07/1960
Diagram: 811	Design Code: NI501		Bogies: BR2

061090	93574	86574	Cardiff Canton T&RSMD	Stores Van
---------------	-------	-------	-----------------------	------------

PASSENGER BRAKE, GANGWAYED

Lot no: 30040	Builder: Wolverton	Ordered: 03/1951	Completed: 01/1955
Diagram: 711	Design Code: NA501		Bogies: BR1

061093	977220	80578	Cardiff Cathays	Stores Van
---------------	--------	-------	-----------------	------------

COVERED CARRIAGE TRUCK (four-wheeled)

Lot no: 30549	Builder: Earlestown	Ordered: 11/1958	Completed: 03/1960
Diagram: 816	Design Code: NP501		

061094	977254	94241	Landore TMD	Staff Van	
Lot no: 30563			Builder: Earlestown	Ordered: 01/1959	Completed: 12/1960
Diagram: 816			Design Code: NP501		
061095	94581		Landore TMD	CCE Staff & Dormitory Van	
Lot no: 30549			Builder: Earlestown	Ordered: 11/1958	Completed: 03/1960
Diagram: 816			Design Code: NP501		
061097	977070	94107	Radyr Yard	Stores Van	Originally at Swindon Cocklebury Yard
061169	977154	94226	Bristol East Yard	CCE Tool Van	

GENERAL UTILITY VAN

GUV

Lot no: 30417			Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811			Design Code: NI501		Bogies: BR2
061171	93480	86480	Reading T&RSMD	Stores Van	
Lot no: 30402			Builder: York/Glasgow	Ordered: 07/1956	Completed: 07/1960
Diagram: 811			Design Code: NI501		Bogies: BR2
061173	93654	86654	Old OakCommon T&RSMD	Stores Van	
Lot no: 30417			Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811			Design Code: NI501		Bogies: BR2
061174	93197	86197	Old OakCommon T&RSMD	Stores Van	Originally at Aylesbury
Lot no: 30616			Builder: Pressed Steel	Ordered: 07/1959	Completed: 06/1960
Diagram: 811			Design Code: NI501		Bogies: BR2
061185	93921	86921	Bristol Marsh Junction OTPD	Stores Van	
Lot no: 30417			Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811			Design Code: NI501		Bogies: BR2
061190	93190	86190	Old Oak Common T&RSMD	Stores Van	Originally at Reading T&RSMD
061202	93498	86498	Plymouth Laura T&RSMD	Stores Van	Grounded body
Lot no: 30616			Builder: Pressed Steel	Ordered: 07/1959	Completed: 06/1960
Diagram: 811			Design Code: NI501		Bogies: BR2
061203	93887	86887	Plymouth Laura T&RSMD	Stores Van	
061204	93927	86927	Plymouth Laura T&RSMD	Stores Van	
Lot no: 30417			Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811			Design Code: NI501		Bogies: BR2
061205	977556	93368	86368 Reading S&T Sidings	S&T Stores Van	
Lot no: 30402			Builder: York/Glasgow	Ordered: 07/1956	Completed: 07/1960
Diagram: 811			Design Code: NI501		Bogies: BR2
061206	977557	93650	86650 Bristol Kingsland Road Yard	S&T Stores Van	
Lot no: 30616			Builder: Pressed Steel	Ordered: 07/1959	Completed: 06/1960
Diagram: 811			Design Code: NI501		Bogies: BR2
061207	977558	93898	86698 Bristol Kingsland Road Yard	S&T Stores Van	
Lot no: 30565			Builder: Pressed Steel	Ordered: 01/1959	Completed: 10/1959
Diagram: 811			Design Code: NI501		Bogies: BR2
061208	93776	86776	St.Blazey	Stores Van	

COVERED CARRIAGE TRUCK (four-wheeled)

CCT

Lot no: 30564			Builder: Earlestown	Ordered: 01/1959	Completed: 03/1961
Diagram: 816			Design Code: NP501		
061210	977080	94631	Westbury	BTU Tool Van	

PASSENGER BRAKE, GANGWAYED

BG

Lot no: 30039			Builder: Derby	Ordered: 03/1951	Completed: 10/1954
Diagram: 711			Design Code: NA501		Bogies: BR1
061216	80559		Old OakCommon T&RSMD	Stores Van	

GENERAL UTILITY VAN

GUV

Lot no: 30417			Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811			Design Code: NI501		Bogies: BR2
061217	93129	86129	Old Oak Common T&RSMD	Stores Van	
Lot no: 30565			Builder: Pressed Steel	Ordered: 01/1959	Completed: 10/1959
Diagram: 811			Design Code: NI501		Bogies: BR2

061223	93714	86714	Oxford Station	Stores Van	
FRUIT VAN 'FRUIT D'					FRUIT D
Lot no: 30345		Builder: Swindon		Ordered: 01/1956	Completed: 06/1958
Diagram: 805					
070836	975172	92048	Bristol East Yard	Stores Van	Originally at Reading CCE Depot
070862	975174	92053	Reading CCE Depot	Stores Van	
070864	975173	92049	Reading CCE Depot	Stores Van	
070888	975347	92060	Oxford Station	Stores Van	
TOURIST OPEN SECOND					TSO
Lot no: 30090		Builder: York		Ordered: 04/1953	Completed: 03/1954
Diagram: 93		Design Code: AC204		Seats: 64S	Bogies: BR1
079171	3986		Swindon Works	Swindon Test Train	
BRAKE CORRIDOR SECOND					BSK
Lot no: 30021		Builder: Ashford/Eastleigh		Ordered: 12/1950	Completed: 11/1952
Diagram: 181		Design Code: AB201		Seats: 24S	Bogies: BR1
079172	34272		Swindon Works	Swindon Test Train	
079173	34280		Swindon Works	Swindon Test Train	
TOURIST OPEN SECOND					TSO
Lot no: 30243		Builder: York		Ordered: 05/1955	Completed: 01/1957
Diagram: 93		Design Code: AC204		Seats: 64S	Bogies: BR1
079174	4526		Swindon Works	Swindon Test Train	
CORRIDOR COMPOSITE					CK
Lot no: 30022		Builder: Ashford/Eastleigh		Ordered: 12/1950	Completed: 11/1952
Diagram: 126		Design Code: AA301		Seats: 24F,18S	Bogies: BR1
079175	15045		Swindon Works	Swindon Test Train	
TOURIST OPEN SECOND					TSO
Lot no: 30090		Builder: York		Ordered: 04/1953	Completed: 03/1954
Diagram: 93		Design Code: AC204		Seats: 64S	Bogies: BR1
079176	3983		Swindon Works	Swindon Test Train	
Lot no: 30086		Builder: Ashford/Eastleigh		Ordered: 04/1953	Completed: 01/1955
Diagram: 93		Design Code: AC204		Seats: 64S	Bogies: BR1
079177	3922		Swindon Works	Swindon Test Train	
CORRIDOR COMPOSITE					CK
Lot no: 30022		Builder: Ashford/Eastleigh		Ordered: 12/1950	Completed: 11/1952
Diagram: 126		Design Code: AA301		Seats: 24F,18S	Bogies: BR1
079178	15031		Swindon Works	Swindon Test Train	
BRAKE CORRIDOR SECOND					BSK
Lot no: 30220		Builder: GRCW		Ordered: 03/1955	Completed: 04/1956
Diagram: 182		Design Code: AB202		Seats: 32S	Bogies: BR1
079179	34863		Swindon Works	Swindon Test Train	
OPEN SECOND					SO
Lot no: 30053		Builder: Eastleigh		Ordered: 10/1951	Completed: 07/1953
Diagram: 90				Seats: 48S	Bogies: BR1
082241	3500		Weymouth	CM & EE Office Coach	Became DS70320
GENERAL UTILITY VAN					GUV
Lot no: 30674		Builder: Doncaster		Ordered: 05/1960	Completed: 05/1960
Diagram: 817					Bogies: Gres
082962	96202	88030	32480 Eastleigh Yard	Stores Van	Fotmerly Car-carrier Van. Originally at Basingstoke Down Yard
FISH VAN					Fish
Lot no: 30344		Builder: Faverdale		Ordered: 01/1956	Completed: 01/1961
Diagram: 801		Design Code: NR502			

083056	87588	Portsmouth & Southsea Station	Stores Van	
BRAKE CORRIDOR SECOND				BSK
Lot no:	30229	Builder: Metro-Cammell	Ordered: 04/1955	Completed: 04/1957
Diagram:	182	Design Code: AB202	Seats: 32S	Bogies: BR1
083172	34989	Basingstoke Down Yard	Staff & Tool Coach	Became ADB977235
TOURIST OPEN SECOND				TSO
Lot no:	30149	Builder: Ashford/Swindon	Ordered: 03/1954	Completed: 03/1957
Diagram:	93	Design Code: AC204	Seats: 64S	Bogies: BR1
083264	4047	Ashford Station Down Sidings	Staff & Stores Coach	Originally at Gillingham EMUD
Lot no:	30090	Builder: York	Ordered: 04/1953	Completed: 03/1954
Diagram:	93	Design Code: AC204	Seats: 64S	Bogies: BR1
083357	3975	New Cross Gate EY	Staff Coach	Originally at Clapham Pig Hill Sidings, later East Croydon
FISH VAN				Fish
Lot no:	30384	Builder: Faverdale	Ordered: 04/1956	Completed: 01/1961
Diagram:	801	Design Code: NR502		
083402	87720	East Croydon	S&T Stores Van	
083403	87820	Tonbridge West Yard	S&T Stores Van	Originally at Three Bridges S&T Yard

COVERED CARRIAGE TRUCK (four-wheeled)				CCT
Lot no:	30562	Builder: Earlestown	Ordered: 01/1959	Completed: 07/1960
Diagram:	816	Design Code: NP501		
083434	94326	Clapham Yard	CM&EE Stores Van	
083438	94347	New Cross Gate WRD	CCE Stores Van	Originally at Wimbledon West Yard
Lot no:	30614	Builder: Earlestown	Ordered: 06/1959	Completed: 04/1961
Diagram:	816	Design Code: NP501		
083439	94752	Wimbledon EMUD	CM&EE Stores Van	Originally at Clapham Yard, later Wimbledon West Yard

BRAKE CORRIDOR SECOND				BSK
Lot no:	30229	Builder: Metro-Cammell	Ordered: 04/1955	Completed: 04/1957
Diagram:	182	Design Code: AB202	Seats: 32S	Bogies: BR1
083527	35016	Horsham Yard	Tool Van	Became ADB975639
Lot no:	30082	Builder: Wolverton	Ordered: 03/1953	Completed: 01/1954
Diagram:	182	Design Code: AB202	Seats: 32S	Bogies: BR1
083574	99607	34307	Salisbury	Exhibition Train Stores Coach

COVERED CARRIAGE TRUCK (four-wheeled)				CCT
Lot no:	30549	Builder: Earlestown	Ordered: 11/1958	Completed: 03/1960
Diagram:	816	Design Code: NP501		
083592	94199	Easleigh Works	Stores Van	
Lot no:	30562	Builder: Earlestown	Ordered: 01/1959	Completed: 07/1960
Diagram:	816	Design Code: NP501		
083593	94351	Eastleigh Works	Stores Van	
Lot no:	30614	Builder: Earlestown	Ordered: 06/1959	Completed: 04/1961
Diagram:	816	Design Code: NP501		
083594	94762	Eastleigh Works	Stores Van	
Lot no:	30563	Builder: Earlestown	Ordered: 01/1959	Completed: 12/1960
Diagram:	816	Design Code: NP501		
083602	977243	94494	Three Bridges Station	Stores Van

PASSENGER BRAKE, GANGWAYED				BG
Lot no:	30228	Builder: Metro-Cammell	Ordered: 04/1955	Completed: 05/1958
Diagram:	711	Design Code: NA501		Bogies: BR1
083603	84128	81128	Wimbledon EMUD	Grounded body
Lot no:	30140	Builder: BRCW	Ordered: 01/1954	Completed: 01/1956
Diagram:	711	Design Code: NA501		Bogies: BR1

083604 80740					Selhurst EMUD	Stores Van	
BRAKE CORRIDOR SECOND							BSK
Lot no: 30003					Builder: Derby	Ordered: 12/1950	Completed: 10/1952
Diagram: 181					Design Code: AB201	Seats: 24S	Bogies: BR1
083614 99608 34063					Cardiff Cathays	Stores Van	Originally at Salisbury
PASSENGER BRAKE, GANGWAYED							BG
Lot no: 30716					Builder: GRCW	Ordered: 07/1961	Completed: 12/1962
Diagram: 711					Design Code: NA501		Bogies: BR1
083616 84611 81611					Selhurst EMUD	Stores Van	
Lot no: 30228					Builder: Metro-Cammell	Ordered: 04/1955	Completed: 05/1958
Diagram: 711					Design Code: NA501		Bogies: BR1
083620 84103 81103					Three Bridges EY	Stores Van	
OPEN SECOND							SO
Lot no: 30053					Builder: Eastleigh	Ordered: 10/1951	Completed: 07/1953
Diagram: 90						Seats: 48S	Bogies: BR1
083621 70320 082241 3500					Ashford West Yard	Instruction Coach	
COVERED CARRIAGE TRUCK (four-wheeled)							CCT
Lot no: 30563					Builder: Earlestown	Ordered: 01/1959	Completed: 12/1960
Diagram: 816					Design Code: NP501		
083631 902612 94477					Selhurst EMUD	LUL Adaptor Wagon	Bodywork removed
GENERAL UTILITY VAN							GUV
Lot no: 30565					Builder: Pressed Steel	Ordered: 01/1959	Completed: 10/1959
Diagram: 811					Design Code: NI501		Bogies: BR2
083632 94054 93721 86721					Brighton EMUD	Stores Van	
083633 94055 93724 86724					Brighton EMUD	Stores Van	
BRAKE CORRIDOR SECOND							BSK
Lot no: 30229					Builder: Metro-Cammell	Ordered: 04/1955	Completed: 04/1957
Diagram: 182					Design Code: AB202	Seats: 32S	Bogies: BR1
083636 99200 35020					Stewarts Lane T&RSMD	Stores Van	Former Bullion Van Originally at Strawberry Hill EMUD
083637 99203 34994					Stewarts Lane T&RSMD	Stores Van	Former Bullion Van Originally at Strawberry Hill EMUD
Lot no: 30095					Builder: Wolverton	Ordered: 04/1953	Completed: 04/1955
Diagram: 181					Design Code: AB201	Seats: 24S	Bogies: BR1
083638 99601 34577					Salisbury	Exhibition Train Stores Coach	
GENERAL UTILITY VAN							GUV
Lot no: 30402					Builder: York/Glasgow	Ordered: 07/1956	Completed: 07/1960
Diagram: 811					Design Code: NI501		Bogies: BR2
083648 93611 86611					Ashford Station Down Sidings	Stores Van	
PASSENGER BRAKE, GANGWAYED							BG
Lot no: 30173					Builder: York	Ordered: 05/1954	Completed: 07/1956
Diagram: 711					Design Code: NA501		Bogies: BR1
083649 95309 80966					Ashford Station Down Sidings	Stores Van	
GENERAL UTILITY VAN							GUV
Lot no: 30417					Builder: Pressed Steel	Ordered: 03/1958	Completed: 01/1959
Diagram: 811					Design Code: NI501		Bogies: BR2
083650 93100 86100					Ashford Station Down Sidings	Stores Van	
BRAKE CORRIDOR COMPOSITE							BCK
Lot no: 30006					Builder: Metro-Cammell	Ordered: 12/1950	Completed: 11/1954
Diagram: 171					Design Code: AB301	Seats: 12F,18S	Bogies: BR1
095024 975210 21019					Perth CS	CCE Staff Coach	Originally at Slateford EY
BRAKE CORRIDOR SECOND							BSK

