Date: 23/02/2021 PRESERVED GREAT WESTERN RAILWAY DESIGN COACHING STOCK

	DEPARTMENTAL	VANS & WAGON	S (new build)	
. VAN				DEPARTMENTAL
)	Built: 1908	Builder: Swindon	4-wheel	
ter Wagon Lot 570 for Break				
DW4	•	ay, Sharpness		
IG VAN				DEPARTMENTAL
j	Built: 1912	Builder: Swindon	4-wheel	
der Wagon Lot 695 for Break DW9	kdown Train use. Severn Valley Railway			
BREAKDOWN CRANE MATCH & COAL WAGON				DEPARTMENTAL
	Built: 1945	Builder: Swindon	4-wheel	
Wagon Lot xxxx for Breakdo	own Train use			
DW19 ADW150445	Weston Wharf, Weston	, Nr Oswestry		
IG VAN				DEPARTMENTAL
)	Built: 1908	Builder: Swindon	4-wheel	
der Wagon Lot 580 for Brea				
	Built: 1908	Builder: Swindon	4-wheel	
-				
DW22				
. VAN	Zacor manay contro			DEPARTMENTAL
	Po:lt: 1021	Puildon Swindon	4 wheel	DETARTMENTAL
		Bulluci. Swilldon	4-WIICCI	
DW66	Severn Valley Railway			
IG VAN				DEPARTMENTAL
)	Built: 1908	Builder: Swindon	4-wheel	
der Wagon Lot 580 for Break	kdown Train use.			
DW89	Severn Valley Railway			
VAN				DEPARTMENTAL
ļ	Built: 1921	Builder: Swindon	4-wheel	
		Cl		
	•	ay, Sharpness		DED DEC
WATER TANKER WAGON Lot: 1555 Diagram: DD.6 Built: 1946 Builder: Swindon 6-wheel				DEPARTMENTAL
e	Built: 1946	Builder: Swindon	6-wheel	
DW101 DW101W				
DW102 ADW102	West Somerset Railway			
DW106 ADW106	Titley Junction Station	, near Kington		
VAN				DEPARTMENTAL
6	Built: 1904	Builder: Swindon	4-wheel	
Built under Wagon Lot 446 for Breakdown Train Use. 109 DW109 Didcot Railway Centre Body only, u/f used for 2511				
DW109 DW112			Body only, u/t used for 2511	
		Builder: Swindon	4-wheel	
		Dunger, Dwilldon	T WHICH	
DW118	Severn Valley Railway			
)	Built: 1908	Builder: Swindon	4-wheel	
Built under Wagon Lot 579 for Breakdown Train use				
DW141				
B Diagram: CC.8	Built: 1913	Builder: Swindon	4-wheel	
DW143	Severn Valley Railway			
	In VAN Ider Wagon Lot 570 for Break DW4 IG VAN Ider Wagon Lot 695 for Break DW9 KDOWN CRANE M Wagon Lot xxxx for Breakd DW19 ADW150445 IG VAN Ider Wagon Lot 580 for Break DW55 VAN Ider Wagon Lot 864 for Break DW66 IG VAN Ider Wagon Lot 580 for Break DW89 VAN Ider Wagon Lot 580 for Break DW89 VAN Ider Wagon Lot 1555 for Break DW92 ER TANKER WAGO Ider Wagon Lot 1555 for Break DW101 DW101W DW102 ADW102 DW106 ADW106 VAN Ider Wagon Lot 446 for Break DW109 DW112 Ider Wagon Lot 446 for Break DW118 Ider Wagon Lot 579 for Break DW141	DEPARTMENTAL VAN Built: 1908 der Wagon Lot 570 for Breakdown Train use. Didcot Railway Centre Vale of Berkeley Railway iG VAN Built: 1912 der Wagon Lot 695 for Breakdown Train use. DW9 Severn Valley Railway KDOWN CRANE MATCH & COAL WA Built: 1945 Wagon Lot xxxx for Breakdown Train use DW19 ADW150445 Weston Wharf, Weston IG VAN Built: 1908 der Wagon Lot 580 for Breakdown Train use. Didcot Railway Centre Built: 1908 der Wagon Lot 571 for Breakdown Train use. DW55 Severn Valley Railway Didcot Railway Centre VAN Built: 1921 der Wagon Lot 864 for Breakdown Train use. DW66 Severn Valley Railway IG VAN Built: 1908 der Wagon Lot 580 for Breakdown Train use. DW66 Severn Valley Railway VAN Built: 1908 der Wagon Lot 580 for Breakdown Train use. DW69 Severn Valley Railway VAN Built: 1921 der Wagon Lot for Breakdown Train use. DW92 Vale of Berkeley Railway ER TANKER WAGON 5 Diagram: DD.6 Built: 1946 der Wagon Lot 1555 for Breakdown Train use. DW101 DW101W Didcot Railway Centre DW102 ADW102 West Somerset Railway DW104 ADW104 Titley Junction Station VAN Built: 1904 der Wagon Lot 446 for Breakdown Train Use. DW109 Didcot Railway Centre DW109 Didcot Railway Centre Severn Valley Railway der Wagon Lot 463 for Breakdown Train use. DW109 Didcot Railway Centre Severn Valley Railway der Wagon Lot 463 for Breakdown Train use. DW118 Severn Valley Railway Didcot Railway Centre Severn Valley Railway Didcot Railway Didcot Railway Centre Severn Valley Railway Didcot Railway Didcot Railway Didcot Railway Didcot Railway Didcot	DEPARTMENTAL VANS & WAGON VAN Built: 1908 Builder: Swindon let Wagon Lot 570 for Breakdown Train use. Didcot Railway Centre DW4 Built: 1912 Builder: Swindon let Wagon Lot 695 for Breakdown Train use. DW9 Severn Valley Railway KDOWN CRANE MATCH & COAL WAGON Built: 1945 Builder: Swindon Built: 1945 Builder: Swindon Built: 1908 Builder: Swindon Built: 1921 Builder: Swindon Built: 1921 Builder: Swindon Built: 1921 Builder: Swindon Built: 1928 Built: 1928 Builder: Swindon Built: 1928 Built: 1928 Builder: Swindon Built: 1928 Builder: Swindon Built: 1928 Builder: Swindon Built: 1928 Builder: Swindon Built: 1929 Builder: Swindon Built: 1921 Builder: Swindon Built: 1924 Builder: Swindon Built: 1924 Builder: Swindon Built: 1924 Builder: Swindon Built: 1924 Builder: Swindon Built: 1904 Builder: Swindon Built: 1908 Built: 1908 Builder: Swindon Built: 1908 Built: 1908 Built: 1908 Builder: Swindon Built: 190	Note

Lot: 579 Built: 1908 Builder: Swindon 4-wheel Built under Wagon Lot 571 for Breakdown Train use. DW146

Lot: 903 Built: 1923 Builder: Swindon

South Devon Railway

Built under Wogon Lot 903 for Breakdown Train use.

146

RIDING VAN

DW161 Dean Forest Railway 161

4-wheel

Lot: 904 Built: 1923 Builder: Swindon 4-wheel

Built under Wagon Lot 904 for Breakdown Train use.

DW162 162 Severn Valley Railway

STAFF AND TOOL VAN

Lot: 1037 Built: 1930 Builder: Swindon Bogied

Built under Wagon Lot 1073 for Breakdown Train use.

174 DW174 TDM174W **Tyseley Locomotive Works** **DEPARTMENTAL**

DEPARTMENTAL

DEPARTMENTAL VANS & WAGONS (ex freight stock)

STAFF AND TOOL VAN **DEPARTMENTAL** Lot: 549 Built: 1907 Builder: Swindon 4-wheel Built under Wagon Lot 549 as Toad Brake Van 17711. Converted for S&T use. 262 DW262 Railway Support Services, Rye Farm, Wishaw Lot: 477 Built: 1905 Builder: Swindon 4-wheel Built under Wagon Lot 477 as Toad Brake Van 56867. Converted for S&T use. 263 DW263 **Didcot Railway Centre** STORES VAN **DEPARTMENTAL** Built: 1914 Builder: ? 4-wheel Built as Iron Mink for Barry Railway numbered 1388, becoming GWR 48901. Conveerted for Traffic Department use. Used as Internal User at Shrewsbury Station. DW298 024303 Gloucestershire-Warwickshire Railway 298 STAFF VAN **DEPARTMENTAL** Lot: Built: 1898 Builder: Swindon 4-wheel Built under Wagon Lot xxxx as Toad Brake Van 56322. Converted for CCE use. Used as Internal User at Honeybourne Tip. 300 DW300 070837 **Eight One Three Fund, Honeybourne** TOOL VAN **DEPARTMENTAL** Built: 1910 Builder: Swindon 4-wheel Built on Wagon Lot xxx as Mink 26919. Converted for S&T use. 80964 KDW80964 Helston Railway, Cornwall PACKING VAN **DEPARTMENTAL** Built: 1923 Builder: Swindon 4-wheel Built under Wagon Lot xxx as Mink A 101961. Converted for Breakdown Train use. 150066 DW150066 Severn Valley Railway TEST WEIGHTS WAGON **DEPARTMENTAL** Built: 1899 Builder: Swindon 4-wheel Built on Wagon Lot xxx as Ballast Wagon 80005. Converted for use by Pooley Weighing Machine Contractor's. 150260 DW150260 Gloucestershire-Warwickshire Railway Built: 1900 Built on Wagon Lot xxx as Ballast Wagon 60562. Converted for use by Pooley Weighing Machine Contractor's.

150262 DW150262

Severn Valley Railway